



# ACR PRO ALICE PLUS

用户手册  
User Manual

# 目录

---

组合键功能(Windows)	1
组合键功能(Mac)	2
系统功能	3
背光调节	4
按键 / 灯光自定义说明和调用说明	5

# ■ Menu

---

HotKeys (Windows) .....	6
HotKeys (Mac) .....	7
System Commands .....	8
Backlight Settings .....	9
Key/Lighting Effects Customization Instruction .....	10

# 组合键功能(Windows)

注：以下功能通过Fn+对应键组合实现

1	F1	9	F9	Esc	~
2	F2	0	F10	C	计算器
3	F3	-	F11	M	静音
4	F4	=	F12	<	音量减小
5	F5	PgUp	Home	>	音量增大
6	F6	PgDn	End	W	将 W A S D 与 ↑ ↓ ← → 键对调
7	F7	I	Insert		
8	F8	P	PrtSc		

注：以下功能通过Fn+对应键组合实现

1	降低显示亮度	-	音量减小	M	静音
2	增加显示亮度	=	音量增大	<	音量减小
3	开放任务控制	PgUp	Home	>	音量增大
4	呼出Siri	PgDn	End	W	将 W A S D 与 ↑ ↓ ← → 键对调
7	向后跳(音频)	I	Insert		
8	暂停/播放(音频)	P	PrtSc	左Win	Option
9	向前跳过(音频)	Esc	~	左Alt	Command
0	静音	C	计算器	右Alt	Command

锁Win键

Fn + 左Win

恢复出厂设置

长按Fn+ Backspace 5秒

进入Windows系统

长按Fn + Q 3秒

进入Mac系统

长安Fn + O 3秒

注：以下功能通过Fn+对应键组合实现

L	灯光关闭/开启
↑	灯光变亮
↓	灯光变暗
←	灯光方向向左
→	灯光方向向右
;	灯光速度变慢
'	灯光速度变快
Z	侧边灯光亮度切换，5档，循环
X	侧边灯光速度切换，5档，循环
左Ctrl	侧边灯光模式切换，包括关闭 共6种

Delete	常亮、呼吸、霓虹、光波、涟漪、繁星点点、川流不息、如影随形、聚合、正弦波彩泉涌动、百花争艳、一石二鸟、峰回路转、斜风细雨、雨滴、流星、踏雪无痕、层出不穷、极光（共20种）
\	在所有灯效RGB彩光模式下，调节灯光颜色致7色单色+RGB循环
空格	在侧边灯光模式，调节灯光颜色致7色单色+RGB循环

1. 键盘按键/灯光自定义需配合驱动进行。
2. 键盘有线模式下灯光可搭配驱动实现音乐律动。
3. 按键/灯光自定义及调用说明；请在我司官网下载“Akko Cloud”驱动。
4. 驱动下载地址[www.akkogear.com](http://www.akkogear.com)



# HotKeys (Windows)

Note: The following features are realized by the combination of “Fn” + corresponding key

1	F1	9	F9	Esc	~
2	F2	0	F10	C	Calculator
3	F3	-	F11	M	Mute
4	F4	+	F12	<	Decrease Volume
5	F5	PgUp	Home	>	Increase Volume
6	F6	PgDn	End	W	Swap W A S D with ↑ ↓ ← →
7	F7	I	Insert		
8	F8	P	PrtSc		

# Hotkeys (Mac)

Note: The following features are realized by the combination of “Fn” + corresponding key

1	Decrease display brightness	-	Decrease Volume	M	Mute
2	Increases display brightness	+	Increase Volume	<	Decrease Volume
3	Open mission control	PgUp	Home	>	Increase Volume
4	Activate Siri	PgDn	End	W	Swap W A S D with ↑ ↓ ← →
7	Skip back (Audio)	I	Insert		
8	Pause/Play (Audio)	P	PrtSc	Left Win	Option
9	Skip forward (audio)	Esc	~	Left Alt	Command
0	Mute	C	Calculator	Right Alt	Command

Lock Windows Key    Press Fn and left Win key

---

Restore Factory Settings    Hold down Fn and press Backspace key for 5S

---

Enter Windows system    Hold down Fn and press Q key for 3S

---

Enter Mac system    Hold down Fn and press O key for 3S

---

# Backlight Settings

Note: The following features are realized by the combination of “Fn” + corresponding key

L	Light On / Off	Delete	Effect1 - Effect20
↑	Bright	\	In all multi-color RGB lighting effects, this shortcut allows you to set the backlight to 7 single color with RGB loop effect.
↓	Dim		
←	Set animation direction to left	Spacebar	Set the acrylic case backlight to 7 single color with RGB loop effect.
→	Set animation direction to right		
;	Slower Animation		
'	Faster Animation		
Z	Acrylic Case Light Brightness Change		
X	Acrylic Case Light Animation Speed Change		
left Ctrl	Acrylic Case Light Effect Change		

# Key/Lighting Effects Customization Instruction

---

1. The key/lighting effects customization must with Akko driver.
2. In wired mode, the lighting effects can also achieve music rhythm effects with Akko driver.
3. Please download the Akko Cloud driver on our website.
4. Users can download the driver via [en.akkogear.com](http://en.akkogear.com)

