



ACRYLIC<sup>87</sup>

用户手册  
User Manual

# 目录

---

系统功能 .....	1
灯光功能 .....	2
Akko Macro V1.0宏定义功能说明1 .....	3
Akko Macro V1.0宏定义功能说明2 .....	4
Akko Macro V1.0宏定义功能说明3 .....	5
Akko Macro V1.0宏定义的调用 .....	6
Akko售后服务规范 .....	7

# Menu

---

System Commands .....	8
Backlight Settings .....	9
Akko Macro V1.0 Macro Setup Instruction 1 .....	10
Akko Macro V1.0 Macro Setup Instruction 2 .....	11
Akko Macro V1.0 Macro Setup Instruction 3 .....	12
Akko Macro V1.0 Calling Macros .....	13
Akko Warranty and Service Statement .....	14

注：以下功能通过Fn+对应键组合实现

F1	我的电脑	C	计算器
F2	电子邮件	M	静音
F3	Windows搜索	<	调低音量
F4	浏览器主页	>	调高音量
F5	多媒体播放器	左Win	锁Win
F6	播放/暂停	W	将W A S D 与 ↑ ↓ ← → 键对调
F7	上一首		
F8	下一首		

恢复出厂设置

长按 左Win + 右win键 5秒

将Ctrl变成Menu (APP) 键

长按 Fn + 右Ctrl

注：以下功能通过Fn+对应键组合实现

F9	侧边灯光变快
F10	侧边灯光变慢
F11	侧边灯光变暗
F12	侧边灯光变亮
-	灯光速度变慢
+	灯光速度变快
ScrLK	灯光开启或关闭
↑	灯光亮度变亮
↓	灯光亮度变暗
←	灯光方向变化
→	灯光颜色切换


Ins	灯光模式1
Del	灯光模式2
Home	灯光模式3
End	灯光模式4
PgUp	灯光模式5
PgDn	灯光模式6

# ■ Akko Macro V1.0宏定义功能说明 1

---

1. 自定义功能无需驱动程序, 根据说明操作可直接使用。
2. “Esc”, “Fn”, “左Win键”, “右Win键”四颗功能键无法自定义。
3. 目前Akko Macro V1.0不支持同时触发, 即“AB”同时按下依然以A, B顺序触发。
4. 目前Akko Macro V1.0不支持自定义间隔时间, 即无法定义A, B之间的间隔, 不论你按的快或者慢, 都会以系统默认的触发时间定义。

# Akko Macro V1.0宏定义功能说明 2



## 清除宏：

如果该按键已经进行了自定义,当进入自定义模式后,按下FN+该按键则会清除该按键的宏。  
如果要对该按键重新进行自定义,则在清除宏后再按照正常步骤按下FN+该键,开始自定义。

## 宏定义示例:将A定义成 akkogear

第一步:长按Fn+左Win 3秒,进入自定义层

第二步:按Fn+Esc,开始宏定义

第三步:按Fn+A,选择A开始宏定义

第四步:按照顺序按下a,k,k,o,g,e,a,r

第五步:按Fn+A,结束A的宏定义

此时,按A就会显示akkogear,如果您还要对B进行宏定义,按下Fn+B,开始B的宏定义

第六步:按Fn+Esc退出宏定义

在自定义层下,就可以操作您设置的键位和宏了

第七步:长按Fn+左Win 3秒,退出自定义层,回到默认键位



## 方法一：

进入自定义层(长按Fn+左Win),进入自定义层之后,所有按键变成已经自定义的内容,同时Win被锁,如果想使用Win,按下Fn+Win解锁。在这个模式下,您可以任意的使用已经编辑好的按键。自定义层不被记录,关机或者插拔后需要会恢复到默认键位,需要重新操作后进入自定义层。

## 方法二：

在默认键位下,通过Fn+右Alt+已经定义的按键,快速调用该按键的自定义内容,注意一定要按照先按Fn再按Alt的顺序调用。

1. Akko机械键盘享受非人为损坏1年保修服务, 即从购买日起, 1年以内免费维修。
2. 如超过条款1的保修期限, Akko官方将收取不超过市场平均价格的费用提供维修服务。
3. 用户自行拆开键盘视为放弃免费维修服务, 即使1年内损坏, 也按照售后服务条款2执行。
4. 不同销售平台的特殊服务条款, 以购买平台规则为准。

## 注意 事项

人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等, 键盘为电子产品, 请按照电子产品保护方式爱惜使用。

售后电话:0755-27728007

售后QQ:981572876

\*官方售后服务时间为每周一至周五上午10:00至下午18:00, 节假日以国家法定节日休息为准。

\*因受维修时间, 物流时间, 零件采购时间等不可控因素, 售后时间会有不同, 以实际损坏情况评估为准, 请用户耐心等待。

# System Commands

Note: The following features are realized by the combination of "Fn" + corresponding key

F1	File Explorer	C	Calculator
F2	E-mail	M	Mute
F3	Windows Search	<	Decrease Volume
F4	Browser Homepage	>	Increase Volume
F5	Media	Left Win	Lock Win
F6	Pause /Playback	W	Swap W A S D with ↑ ↓ ← →
F7	Previous Song		
F8	Next Song		

## Restore Factory Settings

Press and hold the  
left Win + right Win together  
for 5 seconds.

## Revert Ctrl into Menu (APP) key

Hold down Fn and press right Ctrl

# Backlight Settings

Note: The following features are realized by the combination of "Fn" + corresponding key

F9	Acrylic Case Light Animation Faster
F10	Acrylic Case Light Animation Slower
F11	Acrylic Case Light Dimmer
F12	Acrylic Case Light Brighter
-	Slower Animation
+	Faster Animation
ScrLK	Light On / Off
↑	Bright
↓	Dim
←	Change Animation Direction
→	Change Color

Ins	Lighting Effect A
Del	Lighting Effect B
Home	Lighting Effect C
End	Lighting Effect D
PgUp	Lighting Effect E
PgDn	Lighting Effect F


# Akko Macro V1.0 Macro Setup Instruction 1

---

1. Akko Macro V1.0 is hardware-based and works without software-driven.
2. The following keys cannot be programmed: "Esc", "Fn", "Left Win" and "Right Win".
3. Akko Macro V1.0 does not support simultaneous trigger, that is, pressing "AB" at the same time will trigger the two keys in the order of A followed by B.
4. Akko Macro V1.0 does not support customized interval time, that is, the trigger interval between key A and key B cannot be defined and will follow the system's default trigger time.

# Akko Macro V1.0 Macro Setup Instruction 2

11



If a key has been defined, after entering the Macro editor, you can press "FN + the key" to clear its definition.

## Clear Macro:

If you want to re-customize that key, press "FN + the key" again to start the new Macro recording after clearing its old definition.

# Akko Macro V1.0 Macro Setup Instruction 3

---

## Macro Recording Example: Define "A" as "AKKOGEAR"

Step 1: Press Fn + left Win for 3 seconds to enter the Macro mode.

Step 2: Press Fn + ESC to launch Macro editor.

Step 3: Press Fn + A. This means we choose key "A" to record.

Step 4: Press A, K, K, O, G, E, A, R in order as replacement definition of "A".

Step 5: Press Fn + A again to end the Macro recording of key "A".

At this point, pressing "A" in notepad will display "AKKOGEAR".

If you want to create a Macro for key "B", press Fn + B to start the Macro recording.

Step 6: Press Fn + Esc to exit Macro editor.

Under the Macro mode, you can configure the keys and Macros you set.

Step 7: Press and hold Fn + Left Win for 3 seconds to exit the Macro mode and return to the default key definition.

## Method A:

Enter the Macro mode by long pressing Fn+left Win. Then all keys will turn to pre-configured definitions with locked Win key. Press Fn+Win to unlock Win key if necessary. In the Macro mode, you can use keys with customized definitions. Note, everytime you reboot or re-plugged the cable of the keyboard, the Macro mode will be turned off by default and all keys will return to default definitions until you re-enter the Macro mode.

## Method B:

Under the default key definition, you can also quickly call the customized content of specific keys through "Fn+right Alt+the key that has been defined through Macro". Note that you must first press Fn and then press Alt to call the Macro.



1. Akko provides 1-yr warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.
3. Disassembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

## Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.



扫描关注官方微信



扫描关注官方微博



[instagram.com/akkogear](https://www.instagram.com/akkogear)



[facebook.com/akkogear](https://www.facebook.com/akkogear)