



# MOD007PC

## 有线键盘用户手册

User Manual

快速开始指南 ▶


Quick Guide

# 感谢您购买及使用本产品



为了给您带来更好的使用体验，在使用产品前请仔细阅读本说明书，并请妥善保管，以便日后参观。

## 产品概览



## 包装内容



## 系统需求

Windows®XP / Vista / 7 / 8 / 10或更高版本

## 安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。


## 指示灯说明

状态	指示灯位置	指示方式
Caps	Caps键	白光常亮
锁Win	左Win键	白光常亮

## 调整按键行程快捷键

Fn+1	轴行程为2mm	Fn+2	轴行程为0.5mm
Fn+3	轴行程为0.5mm+火力模式		
Fn+4	驱动自定义轴行程通道，默认2mm轴行程		

## MOD007PC 组合键功能





Fn+	F1	我的电脑
	F2	电子邮件
	F3	= Windows搜索
	F4	浏览器主页
	F5	多媒体播放器

Fn+	F6	播放 / 暂停
	F7	上一首
	F8	= 下一首
	C	计算器
	M	静音

Fn+	<	音量减小
	>	音量放大
	P	= Print SCR
	I	Insert
	W	将WASD与 ↑↓←→键对调

## MOD007PC 系统功能 (Windows)





**旋钮功能**

- 默认为音量功能
- 逆时针为调低音量
- 顺时针为调高音量

---

- 按下中间切换为亮度功能
- 逆时针为降低亮度
- 顺时针为增加亮度

**锁Win键**

Fn + 左Win

**恢复出厂设置**

长按 Fn+~ 5秒


**Win系统 ⇌ Mac系统**

长按 Fn + O 3秒

**切换成菜单键 (可记忆)**


长按 Fn + 右Ctrl 3秒

## MOD007PC 系统功能 (Mac)



F1	降低显示屏亮度	F7	上一曲	F11	调低音量
F2	增加显示屏亮度	F8	暂停/播放(音频)	F12	调高音量
F3	开放任务控制	F9	下一曲	左Win	Option
F4	呼出Siri	F10	静音	左Alt	Command
右Alt	Command	Fn + (F1-12)	F1 ~ F12		

## MOD007PC 灯光调节



Fn+←	灯光速度变慢	Fn+Home	常亮、涟漪、如影随形、川流不息、流星
Fn+=	灯光速度变快	Fn+PgUp	繁星点点、霓虹、光波、层出不穷、彩泉涌动
Fn+↑	灯光变亮	Fn+End	呼吸、极光、正弦波、雨滴、峰回路转
Fn+↓	灯光变暗	Fn+PgDn	斜风细雨、踏雪无痕、聚合、一石二鸟、百花争艳
Fn+←	灯光方向向左	Fn+\	在RGB彩光模式下, 调节灯光颜色致7色单色+RGB循环
Fn+→	灯光方向向右		
Fn+L	灯光关闭/开启		

## 按键/灯光自定义说明和调用说明

1. 键盘按键/灯光自定义可配合驱动进行
2. 键盘灯光可搭配驱动实现音乐律动
3. 请在我司官网下载“Akko Cloud”驱动
4. 驱动下载地址[www.akkogear.com](http://www.akkogear.com)

## Akko保修和服务声明

1. Akko为中国大陆的客户提供一年保修。对于其他地区，请联系您的卖家（Akko分销商）以了解具体的保修政策。
2. 如果保修期到期，客户需要支付维修费用。如果用户喜欢自己修理键盘，Akko也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。
3. 在未经制造商/卖方指示的情况下拆开键盘将立即导致保修无效
4. 官方售后服务时间为每周一至周五上午10:00至下午18:00，节假日以国家法定节日休息为准。
5. 退货和保修政策在不同的平台上可能有所不同，并在购买时取决于具体的经销商。

公司：深圳银宸科技有限公司

地址：深圳市宝安区松岗街道碧头第一工业区朗碧路33号

电话：0755-23216420

网址：[www.akkogear.com](http://www.akkogear.com)

产地：中国·深圳

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China



WARNING:

Water and Beverages can't be poured into the Keyboard.




中国制造/Made in China

**注意  
事项**

人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等，键盘为电子产品，请按照电子产品保护方式爱惜使用。

To provide you with a better user experience, please read this manual carefully before using the product.

## Overview



## Packing List



## System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version

## Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.


## Indicator Description

Status	Indicator Position	Indication Mode
Caps	Caps key	Steady White
Lock Win	Left Win key	Steady White

## Shortcuts to Adjust Travel Distance

<b>Fn+1</b>	Switch Travel Distance = 2mm	<b>Fn+2</b>	Switch Travel Distance = 0.5mm
<b>Fn+3</b>	Switch Travel Distance = 0.5mm + Ultra Sensitive Mode		
<b>Fn+4</b>	Customize switch actuation distance through Akko Cloud Driver (2mm by default)		

## MOD007PC HotKeys





Fn+	F1	My Computer
	F2	E-mail
	F3	= Windows Search
	F4	Browser Homepage
	F5	Media

Fn+	F6	Pause/Playback
	F7	Previous Song
	F8	= Next Song
	C	Calculator
	M	Sound off

Fn+	<	= Decrease Volume
	>	Increase Volume
	P	= Print SCR
	I	Insert
	W	Swap W A S D with ↑ ↓ ← →

## MOD007PC System Commands (Windows)





**Rotary Knob**

Default is volume function;  
 Rotate counterclockwise to decrease the volume;  
 Rotate clockwise to increase the volume.

Press the middle to switch to brightness function;  
 Rotate counterclockwise to decrease brightness;  
 Rotate clockwise to increase brightness.

### Lock Windows Key

Press Fn and  
Left Win Key

### Revert Ctrl into Menu Key (Memorable)

Hold down Fn  
and press Right Ctrl Key for 3S


### Restore Factory Settings

Hold down Fn and  
press ~ Key for 5S

### Win System ⇌ Mac System

Hold down Fn and  
press O Key for 3S

## MOD007PC System Commands (Mac)



F1 Decrease display brightness

F2 Increase display brightness

F3 Open mission control

F4 Activate Siri

F7 Skip back (Audio)

F8 Pause/Play (Audio)

F9 Skip forward (Audio)

F10 Mute

F11 Decrease Volume

F12 Increase Volume


Left Win Option

Left Alt Command

Right Alt Command

Fn + (F1-12) F1 ~ F12

## MOD007PC Backlight Settings



Fn+- Slower Animation

Fn+= Faster Animation

Fn+L Light On / Off

Fn+↑ Bright

Fn+↓ Dim

Fn+← Set Animation Direction to Left

Fn+→ Set Animation Direction to Right

Fn+Home

Fn+PgUp

Fn+End

Fn+PgDn

Fn+\

Effect1, Effect2, Effect3, Effect4, Effect5

Effect6, Effect7, Effect8, Effect9, Effect10

Effect11, Effect12, Effect13, Effect14, Effect15

Effect16, Effect17, Effect18, Effect19, Effect20

In all lighting effects with RGB colormode, Set the backlight color to 7 single color with RGB loop effect.



## Customization Instruction

1. The key/lighting effects customization can be programmed with Akko Cloud Driver
2. The lighting effects can also achieve music rhythm effects with Akko Cloud Driver
3. Please download the Akko Cloud Driver on our website
4. Users can download the driver via [en.akkogear.com](http://en.akkogear.com)

## Akko Warranty and Service Statement

1. Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.
3. Disassembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: [www.akkogear.com](http://www.akkogear.com)

Origin: Shenzhen, China



**WARNING:**

Water and Beverages can't be poured into the Keyboard.



[instagram.com/akkogear](https://www.instagram.com/akkogear)



[facebook.com/akkogear](https://www.facebook.com/akkogear)

中国制造/Made in China



[tiktok.com/@akkogear](https://www.tiktok.com/@akkogear)

### Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.



[www.akkogear.com](http://www.akkogear.com)

