



Akko

MOD008

用户手册

User Manual

# 目录

---

组合键功能(Windows)	1
组合键功能(Mac)	2
系统功能	3
背光调节	4
按键 / 灯光自定义说明和调用说明	5

# ■ Menu

---

HotKeys (Windows) .....	6
HotKeys (Mac) .....	7
System Commands .....	8
Backlight Settings .....	9
Key/Lighting Effects Customization Instruction .....	10

# 组合键功能(Windows)

注：以下功能通过Fn+对应键组合实现

1	F1	9	F9	C	计算器
2	F2	0	F10	M	静音
3	F3	-	F11	<	音量减小
4	F4	+	F12	>	音量增大
5	F5	PgUp	Home	W	将 W A S D 与 ↑ ↓ ← → 键对调
6	F6	PgDn	End		
7	F7	I	Insert		
8	F8	P	PrtSc		


注：以下功能通过Fn+对应键组合实现

1	降低显示亮度	-	音量减小	<	音量减小
2	增加显示亮度	+	音量增大	>	音量增大
3	开放任务控制	PgUp	Home	W	将 W A S D 与 ↑ ↓ ← → 键对调
4	呼出Siri	PgDn	End		
7	向后跳(音频)	I	Insert	左Win	Option
8	暂停/播放(音频)	P	PrtSc	左Alt	Command
9	向前跳过(音频)	C	计算器	右Alt	Command
0	静音	M	静音		

锁Win键	Fn + 左Win
恢复出厂设置	长按Fn+ Backspace 5秒
将Ctrl变成Menu(App)键	长按Fn + 右Ctrl 3秒
进入Windows系统	长按Fn + Q 3秒
进入Mac系统	长安Fn + O 3秒

注：以下功能通过Fn+对应键组合实现

[	灯光速度变慢
]	灯光速度变快
L	灯光开启\关闭
↑	灯光变亮
↓	灯光变暗
←	灯光方向向左
→	灯光方向向右
\	在所有灯效 彩光模式下，通过这个快捷键，可以调节灯光颜色致7色单色 + RGB循环。



Del

常亮、呼吸、霓虹、光波、涟漪、繁星点点、川流不息、如影随形、聚合、正弦波、彩泉涌动、百花争艳、一石二鸟、峰回路转、斜风细雨、雨滴、流星、踏雪无痕、极光、层出不穷（共20种）

1. 键盘按键/灯光自定义需配合驱动进行。
2. 键盘有线模式下灯光可搭配驱动实现音乐律动。
3. 按键/灯光自定义及调用说明；请在我司官网下载“Akko Cloud”驱动。
4. 驱动下载地址[www.akkogear.com](http://www.akkogear.com)



# HotKeys (Windows)

Note: The following features are realized by the combination of “Fn” + corresponding key

1	F1	9	F9	C	Calculator
2	F2	0	F10	M	Mute
3	F3	-	F11	<	Decrease Volume
4	F4	+	F12	>	Increase Volume
5	F5	PgUp	Home	W	Swap W A S D with ↑ ↓ ← →
6	F6	PgDn	End		
7	F7	I	Insert		
8	F8	P	PrtSc		

# Hotkeys (Mac)

Note: The following features are realized by the combination of “Fn” + corresponding key

1	Decrease display brightness	-	Decrease Volume	<	Decrease Volume
2	Increases display brightness	+	Increase Volume	>	Increase Volume
3	Open mission control	PgUp	Home	W	Swap W A S D with ↑ ↓ ← →
4	Activate Siri	PgDn	End		
7	Skip back (Audio)	I	Insert	Left Win	Option
8	Pause/Play (Audio)	P	PrtSc	Left Alt	Command
9	Skip forward (audio)	C	Calculator	Right Alt	Command
0	Mute	M	Mute		

Lock Windows Key      Press Fn and left Win key

---

Restore Factory Settings      Hold down Fn and press Backspace key for 5S

---

Revert Ctrl into Menu (APP) key      Hold down Fn and press right Ctrl for 3S

---

Enter Windows system      Hold down Fn and press Q key for 3S

---


Enter Mac system      Hold down Fn and press O key for 3S

---

# Backlight Settings

Note: The following features are realized by the combination of “Fn” + corresponding key

[	Slower Animation
]	Faster Animation
L	Light On / Off
↑	Bright
↓	Dim
←	Set animation direction to left
→	Set animation direction to Right
Del	Effect 1 — Effect 20



In all lighting effects with RGB color mode, this shortcut allows you to set the backlight color to 7 single color with RGB loop effect.

# Key/Lighting Effects Customization Instruction

---

1. The key/lighting effects customization must with Akko driver.
2. In wired mode, the lighting effects can also achieve music rhythm effects with Akko driver.
3. Please download the Akko Cloud driver on our website.
4. Users can download the driver via [en.akkogear.com](http://en.akkogear.com)



# Akko

[www.akkogear.com](http://www.akkogear.com)



@akkogear



扫描关注官方微信



扫描关注官方微博